

285 State Street Suite One North Haven, CT 06473

© Toll Free: (800) 552-9427 © Local: (203) 281-4726 ⇔ Fax: (203) 281-6451

Asphalt Art Foil Application Instructions

Surface Preparation

Prior to application of Asphalt Art the surface temperature must be above 50 degrees F (10 C). The surface should be clean, **dry** and oil-free. Remove any loose debris from the surface. Dirty surfaces may require power washing but, the surface must be dry before application.

Application of Asphalt Art

- 1. Snap a line or otherwise mark the perimeter of the application surface.
- 2. Starting at one corner, remove 6" of liner from the back side.
- 3. Orient the graphic on the surface; Peel back the liner gradually as you are applying the graphic. A back and forth, press and smoothing motion is best.
- 4. Use your fingers, a soft roller or squeegee to work the graphic into any texture or cracks (see pictures at bottom of page). Pay particular attention to the edges making sure they are securely adhered to the surface.
- 5. Using a floor roller, starting at the center and working out covering the entire surface, this helps to secure the Asphalt Art to the surface.
- 6. Repeat process for additional panels if it is a large graphic. Do not overlap the seems!

Removal of Asphalt Art

- 1. Using a scraper to work up one corner.
- 2. Grab the raised corner then pull the material back at a 180-degree angle. The material should pull off in one piece. If the material tears use the scraper to start another edge.
- 3. Adhesive remover may be needed to remove any remaining adhesive from the surface.

Clean Instructions

Under normal traffic, simply sweeping the Asphalt Art with a soft broom will remove most loose particles. When the surface is visibly dirty, cleaning with a soft cloth soap and water will remove most soils.







