

N NEENAH

digiscape®
stick-r
NEW!
"weave"
texture



digiscape® stick-r wide format | 9 mil / 253 gsm C

INSTALLATION INSTRUCTIONS:

- Make sure the wall is smooth, clean and painted before application.
- Remove the liner from the top narrow side of the imaged panel.
- Affix the narrow side of the image to the installation area with a traditional wallpaper smoothing roller (a squeegee is not required and not recommended).
- The product should be applied using the smoothing roller from the inside of the image out with moderate pressure.
- Once satisfied with the location and position of the image on the installation surface, reach under the balance of the image and peel off the liner on a downward diagonal as you continue to use the smoothing roller working the image from the inside to the outside of the image to secure the image and remove the bubbles from the surface.
- Once the image is adhered to the surface of the installation area the image can be trimmed to fit with a sharp exact blade knife or any other suitably sharp razor edge.



800.552.9427 | 203.281.6451 | www.qmls.com