

## Minimum Application Temperature

### Interior Installation

Minimum Room Temperature: 60°F

### Exterior Installation

Minimum Room Temperature: 65°F

### During Warm Months

Early morning or evening installation recommended

## Preparing The Graphic

- After printing the laminating the two films, roll them tightly on the core to prevent the liner from tunneling. Allow the graphic to "relax" 10 minutes before the installation to acclimate to the environment.

## Cleaning Window

- Add lukewarm or warm water to bucket
- Add 16oz bottle of inexpensive isopropyl alcohol to bucket
- Do NOT use any cleaners containing ammonia
- Thoroughly clean window and dry with paper towel or lint-free cloth

## Installation

- Keep printed media in temperate environment (55-85°F) before installation
- Prepare installation solution - fill spray bottle with water and a few drops of baby shampoo or Dawn or Joy (this will allow graphic to be floated into place)
- Thoroughly spray window with installation solution
- Remove top 3-6" of liner and tape graphic into position
- As you remove liner, spray the adhesive and then squeegee from middle to sides as usual
- If you need to reposition, pull up graphic, add more spray and re-squeegee

## Final Comments

- Always leave 1/4 to 3/8" open at edge of window to allow for expansion and contraction
- Use a soft tipped or felt tipped squeegee. Hard squeegees can scratch the graphic
- Should you have questions regarding this process, contact your local area sales manager

