

## Minimum Application Temperature

### Interior Installation

Minimum Room Temperature: 60°F

### Exterior Installation

Minimum Room Temperature: 65°F

### During Warm Months

Early morning or evening installation recommended

## Cleaning Window

- Add lukewarm or warm water to bucket
- Add 16oz bottle of inexpensive isopropyl alcohol to bucket
- Do NOT use any cleaners containing ammonia
- Thoroughly clean window and dry with paper towel or lint-free cloth



## Installation

- Keep printed media in temperate environment (55-85°F) before installation
- Prepare installation solution - fill spray bottle with water and a few drops of baby shampoo or Dawn or Joy (this will allow graphic to be floated into place)
- Thoroughly spray window with installation solution
- Remove top 3-6" of liner and tape graphic into position
- As you remove liner, spray the adhesive and then squeegee from middle to sides as usual
- If you need to reposition, pull up graphic, add more spray and re-squeegee

## Final Comments

- Always leave 1/4 to 3/8" open at edge of window to allow for expansion and contraction
- Use a soft tipped or felt tipped squeegee. Hard squeegees can scratch the graphic
- Should you have questions regarding this process, contact your local area sales manager