

Applications

Retail and Malls

Wayfinding

Events/ Sports

Tradeshows

Museums



Here is a guide to choosing the right combination of **laminates and print media** for your application:

Step One - Choose the Proper Laminate with UL-410 Approved Slip Resistance

InstaShield Floor Guard Economy

Short Term (Up to 90 Days) | Non-PVC 3.75 Mil Polyolefin

InstaShield FG

Long Term (Up to 180 Days) | 5 Mil Semi Rigid PVC

Step Two - Choose the Proper Print Media

DuraVinyl 252

Coated Wood | Ultra Low Tack Adhesive

DuraVinyl 253

Wood and Tile | Removable Adhesive

DuraVinyl 254

Sealed Concrete | Hi Tack Permanent Gray Blockout Adhesive

DuraVinyl 254

Tightly Woven Carpet | Hi Tack Permanent Gray Blockout Adhesive

EcoJet White

Wood and Tile | Non-PVC Solution

Here is an application guide for **one step indoor floor graphics**:

TexWalk by Jessup Manufacturing

14 Mil Textured PVC - ASTM D2047 Non-Slip Certified

Applications

Throw away carpet for events/tradeshows

Short term smooth concrete floors

Short term tile floors

Step One

Print / Trim and apply | Will not shrink

Can be butt seamed

Removal

Follow recommended removal directions that can be found on the TexWalk product page at qmls.com/Texwalk

Contact us today!

Phone: (800) 552-9427 E-mail: info@qmls.com

Web: www.qmls.com

3/28/2018

Application Instructions for Laminate and Print Media Combinations

Product Applications

Quality floor graphic combinations are designed to be applied to smooth, indoor, floor surfaces in good condition, including waxed commercial PVC and ceramic tile.

Floor / Surface Conditions

The floor surface must be clean and dry before applying graphics. Any wax, paint, or coating on the floor surface must have good adhesion to the flooring substrate. Testing for product stability by user is recommended prior to all applications.

Application Instructions

Peel back about 1" of the release liner from top of graphics. Fold and crease liner back. Position graphics starting with top of graphics. Apply firmly using plastic squeegee. Continue removing liner and smooth out graphics with squeegee. After entire graphic is applied, squeegee entire decal, working from the center out, to remove any air bubbles and to ensure good adhesion. Make sure edges are applied well. Product should not be applied using wet method.

Routine Maintenance

Wait 24 hours after application before cleaning or waxing floor. To maintain condition of graphics, avoid exposing graphics to heavy equipment traffic. CAUTION: If edges of graphics begin lifting, replace graphics immediately to avoid risk of injury due to tripping hazard.

Removal Instructions

Lift one edge of graphics and pull using short, quick strokes.

Application Instructions for TexWalk

Recommended application and removal instructions can be found on the TexWalk product page:
qmls.com/Texwalk.

Information provided here is based on research and is believed to be reliable as of printing date. This information does not constitute a warranty. All material should be tested by purchaser to determine final suitability. Quality Media will not be held responsible for customers end use of product. Quality Media is available for directions and advice as to proper use and application of our products.